


White Rubber Coated Fiberglass Tadpole Tape (Tacky Cloth) with Rope Core 550°F / 287°C: Tuff-Flex™ TadpoleTape™ High Temperature *With or Without Wire Insert*



TadpoleTape™ made from Tuff-Flex™ 550 tacky cloth.

This is a widely used tadpole tape that provides a resilient and non-absorbent gasket material for service against steam, air, water and gases.

Especially useful where a rough or uneven surface or flange exists. The fabric is a fiberglass base with a special white rubber formulation. The fabric is tacky, and has a plastic film surface covering that is removed before installation. The fabric will stick to itself once the film is removed.

Same price with and without wire insert.

Available by-the-foot and standard 50 and 100 feet rolls.

Other sizes available.

Wire Inserted Version: The fill (width wise) yarn for this version of the fabric has a twisted brass wired formed with it, providing additional strength, stability and electrical conductivity/shielding.

TadpoleTape™ High Temperature & Heat Resistant White Rubber Coated Fiberglass (Tacky Cloth)		
Rope Core	Stainless Steel or Inconel 600 Mesh Core	Over All Width in / mm
Part Number	Part Number	
TT-FG-TC-RC-M025-16-X-Y	TT-FG-TC-MC-M025-16-X-Y-Z	1.00 / 25
TT-FG-TC-RC-M032-20-X-Y	TT-FG-TC-MC-M032-20-X-Y-Z	1.25 / 32
TT-FG-TC-RC-M038-24-X-Y	TT-FG-TC-MC-M038-24-X-Y-Z	1.50 / 38
TT-FG-TC-RC-M044-28-X-Y	TT-FG-TC-MC-M044-28-X-Y-Z	1.75 / 44
TT-FG-TC-RC-M051-32-X-Y	TT-FG-TC-MC-M051-32-X-Y-Z	2.00 / 51
TT-FG-TC-RC-M063-40-X-Y	TT-FG-TC-MC-M063-40-X-Y-Z	2.50 / 63
TT-FG-TC-RC-M076-48-X-Y	TT-FG-TC-MC-M076-48-X-Y-Z	3.00 / 76

For the “X” value: specify either A, B, C, D, or E

“A” = 3/8” / .375” / 7.9mm; “B” = 1/2” / .500” / 13mm; “C” = 5/8” / .625” / 15.8mm; “D” = 3/4” / .750” / 19mm; “E” = 1” / 1.000” / 25mm

For the “Y” value: specify “W” to specify with wire insert use “N” to specify no wire

For the “Z” value: specify “S” for Stainless Steel or “I” for Inconel

NOTE: 1.0” OAW not available with 5/8, 3/4 or 1” bulb. 1.25” OAW not available with 1” bulb. 1.5” OAW not available with 1” bulb

Curing: It is recommended that this material be cured in situ. This material must be heated to a minimum of 300°F within 60 minutes, then it must sit at 300°F or higher for 90 minutes for the rubber to fully cure.

Do not overtorque the material during this curing time or the rubber will be squeezed off of the base material.

If the material is not fully cured, the rubber will drip from the material causing voids. After curing the material can be exposed to a lower operational temperature.